

ENGLISH OUTSIDE

3.25"

2.9"


FOLD

CLEANING INSTRUCTIONS

- Lid and inner and outer chambers are top rack dishwasher safe
- Do not clean with abrasive cleaners and scrubbers
- Do not clean with products that contain bleach or chlorine

Visit us:
www.primulaproducts.com

Epoca
INTERNATIONAL, INC.
 Boca Raton, FL 33487
 Made in China



INSIDE

3.25"

2.9"

SAFETY INSTRUCTIONS

- Not for microwave or stovetop use
- Odor, taste and stain resistant. Made from food safe materials
- Never use or place in boiling water
- Do not overfill tumbler, hot liquids can scald user
- Always ensure lid is securely fastened before using, hot liquids can scald user

- Not a toy—keep away from small children and pets
- Not for use in the freezer
- Do not drink hot liquids directly from tumbler
- Do not brew tea with lid attached
- **Use caution while tea is brewing as exterior of the tumbler will be hot to the touch**

USAGE INSTRUCTIONS

- Before first use, wash all components separately in warm, soapy water
- Unscrew lid and remove inner chamber
- In the outer chamber, add loose leaf or bagged tea—1–2 teaspoons. Add hot water to the fill line indicator. Follow tea manufacturer's instructions for brewing
- After tea is done brewing, fill the inner chamber with ice, then slowly press it down into the outer chamber
- Securely fasten lid before using
- Use built in carry loop in the lid to easily take on-the-go

Note: If inner chamber becomes hard to remove from the outer, add a little water to wet the silicone base, then turn the inner chamber while pulling outward to remove



FOLD